
 <p>ON Semiconductor® CMOS IMAGE SENSORS</p>	<p>Application Note Product: VITA Family</p> <p>VITA Family Behavioral Model</p>	<p>Date: Jan 2013</p> <p>Issue: rev. 4</p> <p>Page: 1/9</p>
--	---	---

CONTENTS

Introduction.....	2
Directory Structure.....	2
Toplevel Entity, Configuration and Library.....	2
Compilation Order.....	3
Image Files.....	4
Example Testbenches.....	5
Supported Functionality and Limitations.....	6
History.....	8

 ON Semiconductor® CMOS IMAGE SENSORS	Application Note Product: VITA Family VITA Family Behavioral Model	Date: Jan 2013 Issue: rev. 4 Page: 2/9
---	---	--

INTRODUCTION

The VITA model is a VHDL behavioral model. The main objective of this model is to demonstrate the output format and protocol. Upon loading, the model reads an image from file (ppm ASCII format). The model is controlled through its SPI interface. The readout timing is mimicked and the image is transmitted through the LVDS or CMOS interface. The main operation modes, influencing the output protocol, are supported (rolling shutter, global shutter with one or multiple windows, subsampling, etc.).

The primordial purpose of the model is to demonstrate the sensor's interface and frame formatting protocol. The internal latency and timing specifications are not accurate. Additionally, the effect of integration and gain configurations are not modeled.

DIRECTORY STRUCTURE

`${MODEL_ROOT}` is used in the remainder of the document to denote the path of the directory in which the model has been decompressed. The following directory structure is used:

TABLE 1 DIRECTORY STRUCTURE

Directory	Description
<code>\${MODEL_ROOT}/src/</code>	Contains the model's source files (VHDL)
<code>\${MODEL_ROOT}/tb/</code>	Contains example testbenches, instantiating the model's toplevel
<code>\${MODEL_ROOT}/doc/</code>	Contains this document

TOplevel ENTITY, CONFIGURATION AND LIBRARY

TABLE 2 MODEL ENTITY AND CONFIGURATION NAMES

Entity	VHDL Configuration	Description
noiv1sn1300a	cfg_noiv1sn1300a_model	VITA1300 Model, LVDS Outputs
noiv2sn1300a	cfg_noiv2sn1300a_model	VITA1300 Model, CMOS Outputs
noiv1sn2000a	cfg_noiv1sn2000a_model	VITA2000 Model, LVDS Outputs
noiv2sn2000a	cfg_noiv2sn2000a_model	VITA2000 Model, CMOS Outputs
noiv1sn5000a	cfg_noiv1sn5000a_model	VITA5000 Model, LVDS Outputs
noiv1sn025ka	cfg_noiv1sn025ka_model	VITA25k Model, LVDS Outputs



ON Semiconductor®

CMOS IMAGE SENSORS

Application Note Product: VITA Family

VITA Family Behavioral Model

Date: Jan 2013

Issue: rev. 4

Page: 3/9

COMPILATION ORDER

The model is written in VHDL-93 and needs to be compiled into different libraries. The compilation order, together with the target libraries is shown below.

```
lib_vita_hdl    ${MODEL_ROOT}/src/pck_vita_model.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/pck_vita_seq.vhd
lib_model       ${MODEL_ROOT}/src/pck_frame_format.vhd
lib_model       ${MODEL_ROOT}/src/pck_calc.vhd
lib_model       ${MODEL_ROOT}/src/pck_file_io.vhd
lib_model       ${MODEL_ROOT}/src/pck_ppm.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/pck_vita_spi.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_imc.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_spi.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_io.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_pll.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_mux.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_rgen.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_adc.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_seq.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_db_sync.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/pck_crc.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_db_data.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_db.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_clkgen.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_ser_channel.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_ser_par_mux.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita_ser.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/vita.vhd
```

Sensor Specific Compilation (select the file corresponding to the desired VITA model):

```
lib_vita_hdl    ${MODEL_ROOT}/src/noiv1sn1300a.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/noiv2sn1300a.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/noiv1sn2000a.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/noiv2sn2000a.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/noiv1sn5000a.vhd
lib_vita_hdl    ${MODEL_ROOT}/src/noiv1sn25ka.vhd
```


 ON Semiconductor® CMOS IMAGE SENSORS	<p align="center">Application Note Product: VITA Family</p> <p align="center">VITA Family Behavioral Model</p>	Date: Jan 2013 Issue: rev. 4 Page: 4/9
---	--	--

IMAGE FILES

The VITA model uses a ppm format input file, which is an uncompressed ASCII format.

The name of the model's input file is defined by means of the generic *G_IMG_NAME*. The default name is *input.ppm* and the file shall be searched for in the directory from which the simulator is invoked.

Note that the value of generics can be redefined when invoking the simulator. Note that *G_IMG_NAME* contains the image file name, without the extension (.ppm). Optionally a path can be included in the file name.

The size of the image file must correspond with the resolution of the sensor model. The following table lists the required resolution for each model.

TABLE 3 MODEL IMAGE RESOLUTION


Model	y-resolution [pixels]	x-resolution [pixels]
noiv1sn1300a noiv2sn1300a	1024	1280
noiv1sn2000a noiv2sn2000a	1200	1920
noiv1sn5000a	2048	2592
noiv1sn25ka	5120	5120

PPM File Format

A ppm file contains a three lines header, followed by the pixel values in decimal numbers (0-255). The header contains the following information:

TABLE 4 PPM FILE HEADER

Line Number	Description	Example
1	File type (e.g. <i>P2</i>)	P2
2	Resolution	1280 1024
3	Maximum pixel value Only 255 is supported by the model – this is upscaled to 10-bit as needed.	255

 <p>ON Semiconductor®</p> <p>CMOS IMAGE SENSORS</p>	<p>Application Note</p> <p>Product: VITA Family</p> <p>VITA Family Behavioral Model</p>	<p>Date: Jan 2013</p> <p>Issue: rev. 4</p> <p>Page: 5/9</p>
---	--	---

Each pixel of a monochrome image is represented by one 8-bit integer value. Color pixels are represented by three 8-bit values (Red, Green, Blue). The sensor model supports both monochrome and color images and the selection is made by means of the generic G_COLOR (false = monochrome, true = color). This generic has to be set according to the image file format used (default configuration is monochrome).

Note: Some editors add comment lines (i.e. lines starting with the '#' symbol). Comment lines are not supported by the model's parser. Make sure to remove these lines before starting a simulation.

EXAMPLE TESTBENCHES

Testbenches and test cases are included as example in the tb directory. The sensor uploads correspond to the datasheet's values, except for the 'Required Uploads', which are not required for the the model and have been omitted in the example test scenario.

The example test case configures the model for readout of multiple windows in global shutter mode.

In order to simulate the model with the provided examples, one need to compile the following files in the mentioned library, in addition to the model's source).


```
lib_tb_vita_hdl    ${MODEL_ROOT}/tb/src/pck_spi_upload_model.vhd
lib_tb_vita_hdl    ${MODEL_ROOT}/tb/src/pck_tb_vita_model.vhd
lib_tb_vita_hdl    ${MODEL_ROOT}/tb/src/spi_upload_model.vhd

lib_tb_vita_hdl    ${MODEL_ROOT}/tb/noivXsnYYYYa/src/tb_noivXsnYYYYa.vhd
lib_tb_vita_tc      ${MODEL_ROOT}/tb/noivXsnYYYYa/tests/test001/stimuli.vhd
```

Note: Replace X and YYYY with the corresponding values for the desired model.

Simulation can be started for the by loading the following configuration in the simulator:

```
lib_tb_vita_hdl.cfg_tb_noivXsnYYYYa_model
```

 ON Semiconductor® CMOS IMAGE SENSORS	<p align="center">Application Note Product: VITA Family</p> <p align="center">VITA Family Behavioral Model</p>	Date: Jan 2013 Issue: rev. 4 Page: 6/9
---	--	--

SUPPORTED FUNCTIONALITY AND LIMITATIONS


Supported:

- SPI read/write with defaults
- Rolling Shutter Mode – 1 window inclusive black and dummy line generation
- Global Shutter Mode – multiple windows, ev. overlapping, inclusive black line generation
- Triggered Global Shutter
- Subsampled and Binned Readout
- Monochrome and Color readout
- Black Level: set to target level, no auto black level calibration
- 10 bit and 8 bit mode
- Testpattern generation (fixed, incremental, PRBS)
- PLL: basic model regenerating a clock with 5x/4x input clock frequency (no modeling of jitter, startup effects,..)
- Output Format and Protocol
- LVDS Output Mode
- CMOS Output Mode


Limitations:

The following features are not modeled, or modeled with the described limitations.

- Integration Time Control. Integration time can be set, but has no impact on the image data sent out.
- Gains
- AEC
- Black Level Calibration: black level is set to target level, no automatic black level calibration
- Datapath latency (i.e. latency of trigger/sequencer enable to image out)

 <p>ON Semiconductor®</p> <p>CMOS IMAGE SENSORS</p>	<p>Application Note Product: VITA Family</p> <p>VITA Family Behavioral Model</p>	<p>Date: Jan 2013</p> <p>Issue: rev. 4</p> <p>Page: 7/9</p>
---	--	---


- FOT/ROT/line duration: these may deviate from the recommended sensor configuration
- Electro-Optical Artifacts
- Startup Requirements/Upload Sequence: No explicit check
- PLL/Bias/Drivers/... Startup behaviour and transient effects
- Monitor Outputs

 ON Semiconductor® CMOS IMAGE SENSORS	Application Note Product: VITA Family VITA Family Behavioral Model	Date: Jan 2013 Issue: rev. 4 Page: 8/9
---	---	--

HISTORY

TABLE 5 HISTORY

Version	Date	Description
0	October 2011	First draft of noiv1sn1300a model
1	October 2011	Removed monitor2 pin from toplevel wrapper Created noiv1sn2000a (VITA2000) wrapper
2	October 2011	Remodeled PLL such that frequencies < 62 MHz can be used PLL clock is derived from input clock instead of generating fixed frequency clock Corrected 8 bit operation mode
3	December 2012	Added subsampling and binning modes Added error checking and reporting when ROIs are configured incorrectly Corrected SPI readout Updated PLL for faster lock generation (independent of reset to enable time) Added CMOS output variants of VITA1300/2000 (noiv2sn1300a, noiv2sn2000a) Created VITA5000 model (noiv1sn5000a) Created VITA25k model (noiv1sn25ka) Added support for color images (G_COLOR = true) Reformatted manual/readme
4	January 2013	Corrected length of FOT Added Global Shutter Master Mode Modeled the influence of exposure configurations on frame length (no modeling on image luminance)

 <p>ON Semiconductor®</p> <p>CMOS IMAGE SENSORS</p>	<p>Application Note</p> <p>Product: VITA Family</p> <p>VITA Family Behavioral Model</p>	<p>Date: Jan 2013</p> <p>Issue: rev. 4</p> <p>Page: 9/9</p>
---	--	---

ON Semiconductor and the ON logo are registered trademarks of Semiconductor Components Industries, LLC (SCILLC). SCILLC reserves the right to make changes without further notice to any products herein. SCILLC makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does SCILLC assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. "Typical" parameters which may be provided in SCILLC data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. SCILLC does not convey any license under its patent rights nor the rights of others. SCILLC products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the SCILLC product could create a situation where personal injury or death may occur. Should Buyer purchase or use SCILLC products for any such unintended or unauthorized application, Buyer shall indemnify and hold SCILLC and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that SCILLC was negligent regarding the design or manufacture of the part. SCILLC is an Equal Opportunity/Affirmative Action Employer. This literature is subject to all applicable copyright laws and is not for resale in any manner.

PUBLICATION ORDERING INFORMATION

LITERATURE FULFILLMENT:

Literature Distribution Center for ON Semiconductor
P.O. Box 5163, Denver, Colorado 80217 USA
Phone: 303-675-2175 or 800-344-3860 Toll Free USA/Canada
Fax: 303-675-2176 or 800-344-3867 Toll Free USA/Canada
Email: orderlit@onsemi.com

N. American Technical Support: 800-282-9855 Toll Free
USA/Canada.
Europe, Middle East and Africa Technical Support:
Phone: 421 33 790 2910
Japan Customer Focus Center
Phone: 81-3-5773-3850

ON Semiconductor Website: www.onsemi.com

Order Literature: <http://www.onsemi.com/orderlit>

For additional information, please contact your local
Sales Representative